

Sonnenschein SOLAR, SOLAR BLOCK, A600 SOLAR

Operating Instruction

Stationary valve-regulated lead-acid batteries

Nominal data

- Nominal voltage U_N : 2.0 V x number of cells
- Nominal capacity $C_N = C_{100}$ or C_{120} : 100 h or 120 h discharge (see type plate on cells/blocks and technical data in these instructions)
- Nominal discharge current $I_N = I_{100}$ or I_{120} : $I_{100} = C_{100} / 100$ h or $I_{120} = C_{120} / 120$ h
- Final discharge voltage U_f : see technical data in these instructions
- Nominal temperature T_N : 20° C

Battery type : _____ Number of cells/blocks _____
 Assembly by: _____ GNB order no.: _____ date: _____
 Commissioned by: _____ date: _____
 Security signs attached by: _____ date: _____



- Observe these Instructions and keep them located near the battery for future reference.
- Work on the battery should be carried out by qualified personnel only.



- Do not smoke.
- Do not use any naked flame or other sources of ignition. Risk of explosion and fire.



- While working on batteries wear protective eye-glasses and clothing.
- Observe the accident prevention rules as well as EN 50272-2, EN 50110-1.



- Any acid splashes on the skin or in the eyes must be flushed with plenty of clean water immediately. Then seek for medical assistance. Spillages on clothing should be rinsed out with water!



- Warning: Risk of fire, explosion or burns. Do not disassemble, heat above 60°C, or incinerate. Avoid short circuits.
- Avoid electrostatic charges and discharges/sparks!



- Electrolyte is very corrosive. In normal working conditions the contact with the electrolyte is impossible. If the cell/block container is damaged do not touch the exposed electrolyte because it is corrosive.



- Blocks/cells are very heavy! Make sure they are installed securely! Only use suitable means of transport!
- Block/cell containers are sensitive to mechanical damage.
- Handle with care!
- Do not lift or pull up blocks/cells on the poles.**



- Caution! Metal parts of the battery are always alive, therefore do not place items or tools on the battery.



- Keep children away from batteries.

Non-compliance with operating instructions, installations or repairs made with other than original accessories and spare parts or with accessories and spare parts not recommended by the battery manufacturer or repairs made without authorization (e. g. opening of valves) render the warranty void.



Spent batteries have to be collected and recycled separately from normal household wastes (EWC 160601). The handling of spent batteries is described in the EU Battery Directive (2006/66/EC) and their national transitions (UK: HS Regulation 1994 No. 232, Ireland: Statutory Instrument No. 73/2000). Contact your supplier to agree upon the recollection and recycling of your spent batteries or contact a local and authorized Waste Management Company.

Stationary valve regulated lead acid batteries do not require topping-up water. Pressure valves are used for sealing and can not be opened without destruction.

1. Start Up

Check all cells/blocks for mechanical damage, correct polarity and firmly seated connectors. Apply the following torques for screw connectors:

G 5	G 6	A	M 8
5 ± 1 Nm	6 ± 1 Nm	8 ± 1 Nm	20 ± 1 Nm

Rubber covers shall be fitted to both ends of the connector cables (pole covers) before installation.

Control of insulation resistance:
 New batteries: > 1M Ω
 Used batteries: > 100 Ω/Volt.

Connect the battery with the correct polarity to the charger (pos. pole to pos. terminal). The charger must not be switched on during this process, and the load must not be connected. Switch on charger and start charging following item 2.2.

2. Operation

For the installation and operation of stationary batteries EN 50 272-2 is mandatory.

Battery installation should be made such that temperature differences between individual cells/blocks do not exceed 3 degrees Celsius (Kelvin).

2.1 Discharge

Discharge must not be continued below the voltage recommended for the discharge time. Deeper discharges must not be carried out unless specifically agreed with the manufacturer. Recharge immediately following complete or partial discharge.

2.2 Charging

All charging must be carried out acc. to DIN 41773 (IU-characteristic).

Recommended charge voltages for cyclical application: See fig. 1 and item 2.8.

According to the charging equipment, specification and characteristics alternating currents flow through the battery superimposing onto the direct current during charge operation. Alternating currents and the reaction from the loads may lead to an additional temperature increase of the battery, and strain the electrodes with possible damages (see 2.5), which can shorten the battery life.

2.3 Maintaining the full charge (float charge)

Devices complying with the stipulations under DIN 41773 must be used. They are to be set so that the average cell voltage is as follows (within temperature range 15 to 35° C):

SOLAR, SOLAR BLOCK: 2.30 Vpc ± 1%
 A600 SOLAR: 2.25 Vpc ± 1%

2.4 Equalizing charge

Because it is possible to exceed the permitted load voltages, appropriate measures must be taken, e.g. switch off the load. Equalizing charges are required after deep discharges and/or inadequate charges. They can be carried out as follows: Up to 48 hours at max. 2.40 Vpc and with unlimited current. The cell/block temperature must never exceed 45° C. If it does, stop charging or revert to float charge to allow the temperature to drop.

For system voltages ≥ 48 V every one to three months:

Method 1: IUI

I-phase = up to voltage acc. to fig.1 at 20° C
 U-phase = until switching at a current of 1.2 A/100 Ah to the second I-phase
 I-phase = 1.2 A/100 Ah for 4 hours

Method 2: IUI pulse

I-phase = up to voltage acc. to fig. 1 at 20° C
 U-phase = until switching at a current of 1.2 A/100 Ah to the second I-phase (pulsed)
 I-phase = charging of 2 A/100 Ah for 4-6 hours where the pulses are 15 min. 2 A/100 Ah and 15 min. 0 A/100 Ah.




Fig. 1: Charge voltage vs. temperature for solar mode. Charge modes:

- 1) With switch regulator (two-step controller): Charge on curve B (max. charge voltage) for max. 2 hrs per day, then switch over to continuous charge – Curve C
- 2) Standard charge (without switching) – Curve A
- 3) Boost charge (Equalizing charge with external generator): Charge on curve B for max. 5 hrs per month, then switch over to curve C.

2.5 Alternating currents

When recharging acc. to fig.1 the actual value of the alternating current is occasionally permitted to reach 10 A (RMS)/ 100 Ah C_{10} -capacity. In a fully charged state during float charge the actual value of the alternating current must not exceed 5 A (RMS)/ 100 Ah C_{10} -capacity.

2.6 Charging currents

The charging current should range between 10 A to 35 A / 100Ah C_{10} -capacity (guide values). 35 A/100 Ah C_{10} -capacity must not be exceeded in cyclical operation.

2.7 Temperature

The recommended operation temperature range for lead acid batteries is 10° C to 30° C (best 20° C \pm 5 K). Higher temperatures will seriously reduce service life. Lower temperatures reduce the available capacity. The absolute maximum temperature is 55° C and should not exceed 45° C in service.

2.8 Temperature-related charge voltage

The temperature related adjustment has to be carried out acc. to fig. 1. An adjustment of the charge voltage must not be applied within a temperature range 15° C to 35° C.

2.9 Electrolyte

The electrolyte is diluted sulphuric acid and fixed in a gel.

3. Battery maintenance and control

Keep the battery clean and dry to avoid leakage currents. Plastic parts of the battery, especially containers, must be cleaned with pure water without additives.

At least every 6 months measure and record:

- Battery voltage
- Voltage of several blocks/cells
- Surface temperature of several blocks/cells
- Battery-room temperature

If the block/cell voltages differ from the average

float charge voltage by values more than specified in the following table or if the surface temperature difference between blocks/cells exceeds 5 K, the service agent should be contacted.

In addition, annual measurements and recording:

- Voltage of all blocks/cells
- Surface temperature of all blocks/cells
- Battery-room temperature

Type	Upper value	Lower value
2 V cells	+0.2	-0.1
6 V blocks	+0.35	-0.17
12 V-blocks	+0.48	-0.24

Annual visual checks:

- Screw connections
- Screw connections without locking device have to be checked for tightness.
- Battery installation and arrangement
- Ventilation

4. Tests

Tests have to be carried out according to IEC 60896-21, DIN 43539 part 1 and 100 (draft).

Capacity test, for instance, acceptance test on site:

In order to make sure the battery is fully charged the following IU-charge methods must be applied: Option 1: float charge (see item 2.3), \geq 72 hours. Option 2: 2.40 Vpc, \geq 16 hours (max. 48 hours) followed by float charge (see item 2.3), \geq 8 hours. The current available to the battery must be between 10 A/100 Ah and 35 A/100 Ah of the C_{10} -capacity.

5. Faults

Call the service agents immediately if faults in the battery or the charging unit are found. Recorded data as described in item 3. must be made available to the service agent. It is recommended that a service contract is taken out with

your agent.

6. Storage and taking out of operation

To store or decommission cells/blocks for a longer Period of time they should be fully charged and stored in a dry and cold but frost-free room, away from direct sun light. To avoid damage the following charging methods can be chosen:

1. Maximum storage time is 17 months at \leq 20° C. Equalizing charges will be required at higher temperatures, for instance, after 8.5 months at 30° C.
2. Float charging as detailed in 2.3.

7. Transport

Cells/block batteries must be transported in an upright position. Batteries without any visible damage are not defined as dangerous goods under the regulations for transport of dangerous goods by road (ADR) or by railway (RID). They must be protected against short circuits, slipping, upsetting or damaging. Cells/block batteries may be suitable stacked and secured on pallets (ADR and RID, special provision 598). It is prohibited to staple pallets.

No dangerous traces of acid shall be found on the exteriors of the packing unit.

Cells/block batteries whose containers leak or are damaged must be packed and transported as class 8 dangerous goods under UN no. 2794. In case of air transport, batteries which are part of any equipment must be disconnected at their terminals, and the terminals must be protected against short-circuits. This is in order to avoid the risk of any incidents like fire etc.

8. Technical data:

Capacities at different discharge times and final discharge voltage.
All technical data refer to 20° C.

8.1 Sonnenschein SOLAR

Discharge time	1 h	5 h	10 h	20 h	100 h
Capacity	C ₁ [Ah]	C ₅ [Ah]	C ₁₀ [Ah]	C ₂₀ [Ah]	C ₁₀₀ [Ah]
S 12 / 6.6 S	2.90	4.60	5.10	5.70	6.60
S 12 / 17 G5	9.30	12.6	14.3	15.0	17.0
S 12 / 27 G5	15.0	22.1	23.5	24.0	27.0
S 12 / 32 G6	16.9	24.4	27.0	28.0	32.0
S 12 / 41 A	21.0	30.6	34.0	38.0	41.0
S 12 / 60 A	30.0	42.5	47.5	50.0	60.0
S 12 / 85 A	55.0	68.5	74.0	76.0	85.0
S 12 / 90 A	50.5	72.0	78.0	84.0	90.0
S 12 / 130 A	66.0	93.5	104	110	130
S 12 / 230 A	120	170	190	200	230
U _f (cell)	1.7 Vpc	1.7 Vpc	1.7 Vpc	1.75 Vpc	1.80 Vpc

8.2 Sonnenschein SOLAR BLOCK

Discharge time	1 h	5 h	10 h	20 h	100 h
Capacity	C ₁ [Ah]	C ₅ [Ah]	C ₁₀ [Ah]	C ₂₀ [Ah]	C ₁₀₀ [Ah]
SB 12 / 60	34.0	45.0	52.0	56.0	60.0
SB 12 / 75	48.0	60.0	66.0	70.0	75.0
SB 12 / 100	57.0	84.0	89.0	90.0	100
SB 12 / 130	78.0	101	105	116	130
SB 12 / 185	103	150	155	165	185
SB 06 / 200	104	153	162	180	200
SB 06 / 330	150	235	260	280	330
U _f (cell)	1.7 Vpc	1.7 Vpc	1.7 Vpc	1.75 Vpc	1.80 Vpc

8.3 Sonnenschein A600 SOLAR

Discharge time	1 h	3 h	5 h	10 h	100 h
Capacity	C ₁ [Ah]	C ₃ [Ah]	C ₅ [Ah]	C ₁₀ [Ah]	C ₁₀₀ [Ah]
A 602 / 295 Solar	123	167	193	218	286
A 602 / 370 Solar	154	209	241	272	357
A 602 / 440 Solar	185	251	290	326	429
A 602 / 520 Solar	229	307	342	380	505
A 602 / 625 Solar	275	369	410	456	606
A 602 / 750 Solar	321	431	479	532	707
A 602 / 850 Solar	367	513	626	681	829
A 602 / 1130 Solar	489	684	834	908	1105
A 602 / 1415 Solar	612	855	1043	1135	1382
A 602 / 1695 Solar	734	1026	1252	1363	1658
A 602 / 1960 C Solar	824	1209	1359	1573	1937
A 602 / 2600 Solar	1047	1548	1782	2025	2547
A 602 / 3270 Solar	1309	1935	2228	2532	3184
A 602 / 3920 Solar	1571	2322	2673	3038	3821
U _f (cell)	1.67 Vpc	1.75 Vpc	1.77 Vpc	1.80 Vpc	1.85 Vpc

GNB® INDUSTRIAL POWER

Exide Technologies GmbH
Im Thiergarten
63654 Büdingen – Germany

Tel.: +49 (0) 60 42 / 81 544
Fax: +49 (0) 60 42 / 81 398

www.gnb.com

State: July 2012

GNB®
INDUSTRIAL POWER
A Division of Exide Technologies